



INSTALLATION INSTRUCTIONS

MSD GM LS Engine Coil Brackets **For LS1/LS6 Engines, PN 8215** **For LS2/LS7 Engines, PN 8216**

ONLINE PRODUCT REGISTRATION: Register your MSD product online and you'll be entered in our monthly 8.5mm Super Conductor Spark Plug Wire give-away! Registering your product will help if there is ever a warranty issue with your product and helps the MSD R&D team create new products that you ask for! Go to www.msdisignition.com/registration.

Parts Included:

2 - GM LS Engine Coil Brackets
Mounting Hardware (16 bolts)

This MSD Coil Bracket has been designed to dress up the top of GM's LS engines. The 8215 Coil Bracket will work on stock coils for LS1 and LS6 engines or with MSD coil PN 8245. This bracket will NOT work with MSD coil PN 8246 or MSD coil PN 8247.

The 8216 Coil Bracket will work on stock coils for LS2 and LS7 engines or with MSD coil PN 8247. This bracket will NOT work with MSD coil PN 8245 or MSD coil PN 8246. Please ensure the selected bracket part number matches your engine!

PN 82458 - Coil Kits for LS1/LS6 engines
PN 82478 - Coil Kits for LS2/LS7 engines

The brackets are a direct replacement for the stock coil mounting system that enhances the late model look – especially when paired with MSD's Multiple Spark Coils for the LS.

Note: Always use the supplied hardware when installing MSD Coils or Coil Brackets.

1. Disconnect harnesses from the coils.
2. Remove coils from existing brackets
3. Remove existing brackets from top of engine.
4. Install the MSD Coil Brackets using the supplied hardware.
5. Mount coils on MSD Coil Brackets.
6. Reconnect wiring harnesses to coils.



This image shows a blank sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

When returning the unit for repair, leave all wires at the length in which you have them installed. Be sure to include a detailed account of any problems experienced, and what components and accessories are installed on the vehicle. The repaired unit will be returned as soon as possible using Ground shipping methods (ground shipping is covered by warranty). For more information, call MSD Ignition at (915) 855-7123. MSD technicians are available from 7:00 a.m. to 5:00 p.m. Monday - Friday (mountain time).

*Intended normal use means that this item is being used as was originally intended and for the original application as sold by MSD Ignition. Any modifications to this item or if it is used on an application other than what MSD Ignition markets the product, the warranty will be void. It is the sole responsibility of the customer to determine that this item will work for the application they are intending. MSD Ignition will accept no liability for custom applications.